

## Devices Compatible with SPD-4XI-W Deck Pod

### Instruments and Autopilots:

#### **B&G**

10 / 10 HV

Triton

Triton<sup>2</sup>

#### **Furuno**

FI-50 STD Instruments

NAVpilot-300

NAVpilot-711C

#### **Garmin**

GMI 10

GMI™ 20

GNX™

GNX™ 20

GNX™ 21

#### **Nexus**

NX, NX2 Digital, NX2  
Analogue

#### **Northstar**

Explorer 310 Instruments

#### **Raymarine**

i70, p70, p70r

ST290 Analogue

ST60+

ST70

T100 Series

#### **Simrad**

AP24

AP44

IS20

IS35 Digital Gauge

IS42 Digital Display

IS42J Digital Gauge

IS70/IS80

#### **Tacktick**

Maxi Display T100 Series

### Chartplotters and Fishfinders:

#### **B&G**

Vulcan 7 (without flush  
mount)

Zeus Touch 7

Zeus2 7

#### **Furuno**

GP-1871F

#### **Garmin**

EchoMap 7 Series

Echomap Plus 6

Echomap Plus 7

ECHOMAP UHD 6"

ECHOMAP UHD 7"

GPSMAP 720/720s

GPSMAP 722/722xs

GPSMAP 740/740s

GPSMAP 750/750s

Striker 5

Striker 7

Striker Plus 5

Striker Plus 7

STRIKER Vivid 5cv

STRIKER Vivid 7cv

STRIKER Vivid 9sv

#### **Lowrance**

Elite 5/ Mark 5/Elite 5Ti

Elite 7

Elite 7 Ti / Ti2

HDS-5 / HDS-5m / HDS-5x

HDS-7 / HDS-7m

HDS-7 Carbon

HDS-7 Gen 3

HDS-7 LIVE

HDS-7(m) Gen2 Touch

HOOK 7 / 7x

#### **Raymarine**

A65/A67/A68

A75 / A77 / A78

Axiom 7

Axiom 7+

E7/E7D

Element 7 HV

#### **Simrad**

AP48

Cruise 5

Go5 XSE

Go7 (without flush mount)

Go7 XSR

NSS-7

NSS-7 evo2